

RC **Timer** Servo Power Mode Co.,Ltd

RC Timer Programming for Low Voltage 50A, 60A, and 100A

- 1.) Temporarily Remove the propeller, or secure the airplane in case of accidental motor start.
- 2.) Power on transmitter, move throttle to the full ON position.
- 3.) Connect your battery to your model.
- 4.) You will hear the controller beep in sets of three each of 1 - 6 beeps. Move the throttle to the CENTER to select one of the following 6 options. Once selected, it will beep in long and short beeps according to the tables below. To select the final option to program the ESC move the

throttle back to the full ON position. 1 beep: Cut - Off Voltage Settings	
1 short	1 long Auto NiMH, 0.8V per cell
1 short	2 long 7S Lipo 21V Cutoff
1 short	3 long 6S Lipo 18V Cutoff
1 short	4 long 5S Lipo 15V Cutoff
1 short	5 long 4S Lipo 12V Cutoff
1 short	6 long 3S Lipo 9V Cutoff
1 short	7 long 2S Lipo 6V Cutoff
2 beeps: Throttle Range Settings	
2 short, 1 long	Auto Throttle calibration
2 short, 2 long	1.1ms to 1.8ms
2 short, 3 long	Hard Start
2 short, 4long	Soft Start
3 beeps: Brake Settings	
3 short, 1 long	Brake Off
3 short, 2 long	Soft Brake
3 short, 3 long	Medium Brake
3 short, 4 long	Hard Brake
4 beeps: Motor Direction and Cut - Off Type	
4 short, 1 long	Normal Direction
4 short, 2 long	Reverse Direction
4 short, 3 long	Soft Cut - Off
4 short, 4 long	Hard Cutt - Off
5 beeps: Timing Settings	
5 short, 1 long	1° for 2 - 4 pole motors
5 short, 2 long	7° for 6 - 8 pole motors

5 short, 3 long	15° 10 - 14 pole motors
5 short, 4 long	30° 10 - 14 pole fast
6 beeps: PWM Settings	
6 short, 1 long	8KHz